

# worthhome™

## Instructions – Pendant Light Fitting

**No Tools, No Mess. Upgrade any recessed light in minutes! No electrician required.**



### **Adjusts Cord Length Up to 48"**

Wrap the cord around the spindle arm to adjust the cord length to your desired height. Change it any time by readjusting.

### **Screws Into Recessed Light Socket**

Installation is as easy as changing a light bulb. After adjusting the cord length, simply screw the socket adapter into your existing recessed light.



### **Hides Your Existing Recessed Light**

The decorative ceiling canopy slides up tight against the ceiling to hide your existing recessed light. Only you will know it's there.

### **Holds Canopy in Place Without Tools**

The compression nut matches the decorative ceiling canopy and holds the canopy in position. No tools required. Simply turn it clockwise to tighten More

